

PRATHAM WOOD PRODUCTS PVT. LTD.

A - 315, Kanara Business Centre, Off. Ghatkopar Andheri Link Road,
Ghatkopar (East), Mumbai - 400 075. Maharashtra.

Tel: 022 - 2500 3333 / 3332 ~ Fax: 022 - 2500 3331

e-mail: prathamwood@mtnl.net.in , web : www.prathamwoods.com

Procedure of how to fit Glodoor Aqua (Bathroom Doors) :

- Four Sizes are available – **78” x 27”**, **78” x 30”**, **81” x 27”** & **81” x 30”** (Approximately) respectively & Thickness 28mm.
- Carpenter can **adjust the size according to the Customers requirement** i.e. he can **easily cut** the door both vertically & horizontally with the help of **Cutting Machine or any other tool used for cutting Plywood.**
- Now Stick the **PVC Patti / Strips** given along with the Door to the **four sides with the help of SR 998 (Rubber Adhesive) which should be applied on both the sides simultaneously i.e. on Sides of the Doors as well as on Strips / Patti.** Lightly hammer on the four sides with the help of **Rubber / Tafflon hammer. Apply SR 998 (Rubber Adhesive) with the help of Paint Brush.**
- **Always use But-Hinges with zig-zag lining srew hole**, so that it will fit evenly on all the layer of Foam used as a filler.
- **Screw used should be Full Thread with 1.5” length.**
- While fixing the **Handle, Hanger Strip and Stopper use Full thread 1” length Screw**
- One should not use Conceal Locks but can use Cylindrical Locks.
- This door is only for Interior purpose & should not be directly expose to sun.
- Remember, wherever we had made use of the Screw, one should **pour around the Screw a thin lining of Stick Fast / Fevi Quick** for better grip and fitting.