

Pratham Wood Products Pvt. Ltd.

A - 315 , Kanara Business Centre , Link Road , Laxmi Nagar ,

Ghatkopar (East) , Mumbai - 400 075 , Maharashtra

Tel. No. : 022 - 2500 3332 / 3333 ~ Email : prathamwood@ymail.com ~ URL : www.prathamwoods.com



PROCEDURE OF HOW TO FIT GLODOOR AQUA

(100% WATERPROOF DOORS FOR BATHROOMS)

- ❖ Many Standard Sizes available with Door Leaf Thickness 31 mm , Carpenter can adjust the Size as per the Customers Size requirement i.e. it can be easily cut both Horizontally & Vertically in equal proportion from all 4 sides with the help of Plywood Cutting Machine
- ❖ After Customizing the Door as per Buyers Size requirement , now Stick the ABS Strip / C-Channel supplied alongwith Doors on all the 4 Edges with the help of SR 998 (Rubber Adhesive) which should be applied on both the surface simultaneously i.e. on the Door Edges as well as on ABS Strip / C-Channel . After pasting the ABS Strip / C-Channel , lightly hammer all the 4 Edges with the help of Rubber / Tafflon Hammer on all the 4 Sides for best grip
- ❖ Always Use But Hinges with Zig - Zag lining Screw hole , so that it will fit evenly on all the layers of EVA Foam used as filler material inside (For Zig-Zag lining Hinges Image please refer our Catalogue)
- ❖ Screw used should be of Full Thread with 1.5" Length for fixing Hinges , for fixing Handle , Hanger Strip & Stopper please use Full Thread Screw of 1" Length . For making hole for Screw one should make hole with the help of Nail by Tapering it with hammer and should not use Drill Machine anywhere on this Door for Screwing
- ❖ One should not use Conceal Lock but can use Cylindrical Lock
- ❖ Please remember , wherever we had made use of Screw , one should pour around the Screw a thin lining of Stick Fast / Fevi Quick for better grip and fitting

